



# Acer Chromebook CB3-431-C5EX Bottom Panel Replacement

This replacement guide will instruct you on how to replace the bottom panel on your Chromebook.

Written By: Cayley Ho



## INTRODUCTION

This is a fairly easy repair and only requires a Phillips #0 screwdriver and a plastic spudger. Before beginning this repair, make sure to completely power down your computer as it is dangerous to work on the internals of the computer while it is running. Also, remember to handle all of the internal components of your Chromebook with care as they are fragile.

---




### TOOLS:

- [Phillips #0 Screwdriver](#) (1)
  - [iFixit Opening Tools](#) (1)
-

## Step 1 — Bottom Panel



 Working on your device while it is turned on may result in electric shock. Make sure to shut down and unplug your device before you begin.


- Turn device over so the bottom panel is facing you.

## Step 2



- Remove the eight 4mm Phillips #0 screws.
- Remove the two 6mm Phillips #0 screws.

## Step 3



- Insert a plastic opening tool into the crack between the bottom panel and the side of the computer.
- Gently pry the panel off the computer by continuously pulling up and on the panel and moving the plastic opening tool around the crack until the panel comes off.
- Remove the bottom panel and set it aside.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-09-30 03:30:24 AM.